



Installation Instructions for NPMQKR
Nissan Patrol LWB/SWB MQ
150L Replacement Tank

1. Remove the standard fuel tank. Remove the fuel sender unit and breather valve from the standard tank.
2. Modify the sender unit float arm to make it longer with the wire from the fitting kit. Check the float arm travel to ensure that the float arm does not foul on any part of the tank.
3. Fit the fuel sender unit to the new tank using OEM seal and new locking ring. Fit 6mm straight hose barb to expansion box on top of the tank and 12mm straight hose barb into fitting on the top of tank near filler neck. Fit 8mm hose barb elbow to the fuel pick up and 6mm hose barb elbow to the fuel return.
4. Cut the part of the original spare wheel carrier front mount flush with bar.
5. Install the new tank and connect all hoses and fittings. The breather valve from OEM tank must be reinstalled, top of valve marked "TANK" to be connected to 6mm hose barb on expansion box.
6. Fill with fuel and check all hoses and fittings for leaks.

NOTE: Use high quality sealer such as Permatex 3J on all hoses and fittings.



FITTING KIT CONTENTS NPMQKR

Brass	Electrical
<ul style="list-style-type: none"> ○ 1 x P6 5/16 x 1/4 (8mm Hose Barb Elbow) ○ 1 x P6 1/4 x 1/4 (6mm Hose Barb Elbow) ○ 1 x P3 1/2 x 1/4 (12mm Hose Barb Straight) ○ 1 x P3 1/4 x 1/4 (6mm Hose Barb Straight) 	
Bolts / Nuts	Misc Parts
	<ul style="list-style-type: none"> ○ 1 x 2.5mm Wire @ 200mm (To Extend Float Arm) ○ 1 x Locking Ring
Hose Clamps	Cable Ties
<ul style="list-style-type: none"> ○ 6 x 1/4" Hose Clamps ○ 2 x 1/2" Hose Clamps ○ 1 x 2" Hose Clamp 	
Hose	Sender
<ul style="list-style-type: none"> ○ 1 x 6mm Fuel Hose @ 300mm ○ 1 x 6mm Fuel Hose @ 400mm ○ 1 x 8mm Fuel Hose @ 300mm ○ 1 x 12mm CMP Hose @ 500mm 	
Filters	2 Pages Instruction Consisting Of:
	<ul style="list-style-type: none"> ○ 1 x Page Fitting Instructions ○ 1 x Page Fitting Kit Contents

Kit Packed By _____

Kit Checked By _____