

## Installation Instructions for: TH65ER <u>Toyota Hilux RN/LN65 Extra Cab</u> <u>120Lt Replacement Tank</u>

- 1. Remove Rear Section of the drive shaft, taking care to mark splines for later refitting. Remove the rear section of exhaust system and remove heat shield and mounting tabs from the floor pan. Drain and remove original tank.
- 2. Remove fuel sender unit from original tank and position in new tank, adjust float arm length to ensure accurate fuel gauge readings. Fit sender unit to new tank using OEM screws. Screw brass fittings into tank and attach hoses to respective fittings as per diagram.
- 3. Driver's side front shackle may need to be cut to length of shackle bolt nut.
- 4. Lift new tank into position and bolt in place using new bolts provided. Connect all lines and sender unit wires
- 5. Refit drive shaft and modify exhaust system
- 6. Fill tank with fuel and check all hoses and fittings for leaks



## FITTING KIT CONTENTS TH65ER

Brass:	3 Pages of Fitting Instructions Consisting of:
○ 1 x P6 1/4 x 1/4 Elbow	<ul> <li>1 x Page Fitting Instructions</li> </ul>
○ 1 x P6 5/16 x 1/4 Elbow	<ul> <li>1 x Page Kit Content</li> </ul>
○ 1 x P6 1/2 x 1/4 Elbow	<ul> <li>1 x Fitting Diagram</li> </ul>
○ 1 x P3 1/4 x 1/4 Straight	
Bolts / Nuts:	Hose:
o 1 x M10 x 30mm Bolt	o 1 x 6mm Fuel Hose @850mm
○ 1 x M10 Nyloc Nut	o 1 x 6mm Fuel Hose @700mm
o 1 x M10 x 20mm Flat Washer	o 1 x 8mm Fuel Hose @900mm
o 6 x M8 x 25mm Bolt	
○ 1 x M8 Nyloc Nut	
<ul> <li>6 x M8 Spring Washers</li> </ul>	
o 6 x M8 x 25mm Flat Washers	
Hose Clamps:	
o 6 x 1/4" Hose Clamp	
○ 1 x 1/2" Hose Clamp	
o 1 x 2" Hose Clamp	

Kit Packed By\_\_\_\_\_

Checked By \_\_\_\_\_

