

Installation Instructions for TH166SDR <u>Toyota Hilux LN167 Diesel Single Cab</u> 130L Replacement Tank

- 1. Remove rear section of drive shaft taking care to mark spline for later refitting. Drain and remove original tank.
- 2. Remove fuel sender unit and rework as per diagram. Fit sender unit to new tank using OEM screws, check float arm travel by measuring sender resistances before and after fitting. Screw brass fittings into tank, fitting to front of tank is the fuel pick up, fitting to rear of tank is the return. Transfer rollover valve and screws from OEM tank to new tank. Rebend and trim steel tube as per diagram then attach hoses to respective fittings.
- 3. Lift tank into position and bolt in place using new bolts provided. Connect all lines and sender unit wires. Do not leave fuel lines on top of tank when bolting tank up as they will be crushed between the tank and floor stiffening ribs. Cable tie lines up to ribs when tank mounting bolts have been tightened.
- 4. Refit drive shaft, fill tank with fuel and check all hoses and fittings for leaks.




FITTING KIT CONTENTS TH166SDR

Brass:	Electrical:
o 1 x P6 1/4 x 1/4 6mm Elbow	
o 1 x P6 5/16 x 1/4 8mm Elbow	
o 1 x P3 1/2 x 1/4 12mm Straight	
Bolts / Nuts:	Misc Parts:
o 6 x M8 x 25mm Bolts	o 1 x Sender Unit Adaptor Bracket
o 6 x M8 Spring Washers	
o 6 x M8 x 25 x 16g Washers	
o 2 x M5x8mm Pan Head Screws	
o 2 x M5 Nuts	
o 2 x M5 Washers	
Hose Clamps:	Cable Ties:
	o 4 x 11" Cable Ties
Sender:	Pumps & Filters:
Hose:	5 Pages of Fitting Instructions Consisting of:
o 1 x 6mm Fuel Hose @ 1000mm	○ 1 x Page Fitting Instructions
o 1 x 6mm Fuel Hose @ 500mm	○ 1 x Page Fitting Kit Contents
o 1 x 8mm Fuel Hose @ 1000mm	○ 1 x Page Installation Drawing
	o 1 x Page Sender Modification Drawing 97-01
	o 1 x Page Sender Modification Drawing 01+

Kit Packed By	Checked By
---------------	------------

0 0 0 ዎ pick up φ< -Roll over value. rebend vent tube to run like this. 0 0 0

Togoto Hikes S/Cab PHNO THISSOR.



10/01 - Lb

