



Installation Instructions for MTMKEC  
Mitsubishi Triton MK Extra Cab  
135L Replacement Tank

1. Drain and remove the original tank. Disconnect the tail shaft from the diff only.
2. Remove the exhaust pipe from cat to muffler and let the muffler and tail pipe hang down, after removing the hanger bolt at the rear of the muffler.
3. Remove the fuel pump, sender unit and rollover valves from original tank. Lengthen the sender unit float arm by 80mm inverting the float so that it points down. Increase the angle of the top bend on both the float arm and the low fuel light sensor (the rod in the kit is 100mm long to allow for 10mm overlap join). Then fit them to the new replacement tank. (Fit the sender unit first so you can check the float arm travel through the fuel pump hole to see that it does not foul on anything.)
4. Cut the thread of the bolt that protrudes through the cage nut from the left hand rear seat mounting point. Screw the 16mm hose barb into the tank next to the filler.
5. Lift tank into position, connect all hoses, tighten all mounting bolts and hose clamps and refit exhaust and drive shaft. Fill with fuel then start engine and check all hoses and fittings.



## FITTING KIT CONTENTS MTMKEC

<b>Brass:</b>	<b>Electrical:</b>
<ul style="list-style-type: none"> <li>○ 1 x P3 5/8 x 1/4 (16mm Hose Barb Straight)</li> </ul>	<ul style="list-style-type: none"> <li>○ 1 x 3mm Black Single Core Wire @ 200mm</li> <li>○ 2 x Fuel Resistant Shrink Tube @ 25mm</li> </ul>
<b>Bolts / Nuts:</b>	<b>Misc Parts:</b>
<ul style="list-style-type: none"> <li>○ 1 x M10 x 80mm Bolt</li> <li>○ 1 x M10 x 75mm Bolt (1 for RH Rear Mount - 1 to Go Through Front Secondary Bracket Spacer and Tank Mount)</li> <li>○ 2 x M10 Nyloc Nuts</li> <li>○ 4 x M10 Washers</li> <li>○ 2 x M8 x 25mm Bolt (To Mount Secondary Bracket To Front Crossmember)</li> <li>○ 2 x M8 x 20 Washers</li> <li>○ 2 x M8 spring Washers</li> <li>○ 15 x M5 x 10mm Pan Head Screws</li> </ul>	<ul style="list-style-type: none"> <li>○ 1 x Secondary Bracket @ 180mm x 40mm x 5mm with 2 Holes)</li> <li>○ 1 x 2.5mm Rod @ 100mm</li> <li>○ 1 x 2.5mm Rod @ 160mm</li> <li>○ 1 x 55mm Socket (To Use As Spacer on Front Bracket)</li> <li>○ 1 x 80 x 50 x 6 Rubber Band</li> </ul>
<b>Hose Clamps:</b>	<b>Cable Ties:</b>
<ul style="list-style-type: none"> <li>○ 1 x 5/8" Hose Clamp</li> <li>○ 1 x 1 1/2" Hose Clamp</li> </ul>	
<b>Sender:</b>	<b>Pumps &amp; Filters:</b>
<b>Hose:</b>	<b>3 Pages of Fitting Instructions Consisting of:</b>
<ul style="list-style-type: none"> <li>○ 1 x 6mm Fuel Hose @ 1000mm</li> </ul>	<ul style="list-style-type: none"> <li>○ 1 x Page Fitting Instructions</li> <li>○ 1 x Page Fitting Kit Contents</li> <li>○ 1 x Page Sender Rework Diagram</li> </ul>

Kit Packed By \_\_\_\_\_

Checked By \_\_\_\_\_

MTMKEC  
Mitsubishi Triton MK Dual Cab  
Sender Rework Diagram

